



- SHEET NOTES**
1. PROVIDE 4" PERFORATED FOUNDATION DRAIN AROUND BLDG PERIMETER. INCLUDE BACKWATER VALVE.
  2. REMOVE EX SD UNDER PROPOSED BLDG AND REROUTE AS SHOWN ON PLAN.
  3. EX INLET TO BE REMOVED.
  4. PROVIDE BLDG DOWNSPOUT DRAINAGE TO SOUTH STORMWATER PLANTER.
  5. CONNECT TO EX MH.

**CIVIL LEGEND**

BLDG	BUILDING
ELEV	ELEVATION
EX	EXISTING
F	FIRE PROTECTION WATER
FFE	FINISHED FLOOR ELEVATION
FL	FLOW LINE
FT	FEET
LF	LINEAR FEET
SD	STORM DRAIN
SF	SQUARE FEET
SS	SANITARY SEWER
STD	STANDARD
TYP	TYPICAL
W	DOMESTIC WATER
CO	CLEANOUT
WM	WATER METER
- 2"W	DOMESTIC WATER LINE
- 4"F	FIRE PROTECTION WATER LINE
- 6"SD	STORMWATER LINE
- 4"SS	SANITARY SEWER LINE

